GLASS DOOR CLOSERS HINGES





7 Remove the hinges or doors:

Closing power adjustmentTo adjust the power while the door stays in lockingangle,turn the pressure adjusting screw clockwise by 10-23mm with 3mm allen keys,then we got the power that close the door automatically while it is opened at an angle not more than 10-15cm roughly。

This hinge is composed by two leaves, from the endings of this two leaves we may adjust door closing speed and closing power. This is convenient if many hinges are going to be installed at the same time, please steps one by one as following,firstly loose the fixing screw and turn two hinge leaves to an angle of 95°, at which door will stop,then use allen key with scale to put door closing power at 10-15mm position, take off the upper leaf,then fix the upper and lower hinge leaves to doorleaf and door frame accordingly.